

ATX998KL Installation Guide




1: Unscrew the thumb screws from side panel.




2: Pull the side panel back then pull out.



3: Find the motherboard stand-offs from the enclosed screw box.




4: Put the motherboard stand-offs on the motherboard tray.




5: Sit the motherboard on the motherboard tray.



6: Find screws in the screw box.



7. Screw in all the screws into the motherboard stand-offs



8. Same as step 7.

9. Take out front panel: (Optional. Only if you need to install case fans in the front)



Step (1): Unscrew the side Panel (motherboard side)



Step (2): Take out the side panel (motherboard side)



Step (3): There are 6 screws hold the front panel to the case. Unscrew 3 screws at one side from inside of the case.



Step (4): Unscrew the other 3 screws from the other side.



Step (5): Pull out the front panel from the bottom.



10. **Optional:** Install case fan in the front panel (You can put up to 2*80mm fans). Then screw the front panel back.



11. **Optional:** Install case fan at rear (1*80mm-120mm fan)



12. Take out 5.25" metal plate & bay cover by pushing out from inside (you may use a screw driver to force it out)



13. insert 5.25" drives (DVD, CD-R, CD-RW)



14. Secure the 5.25" drives in place with screws.




15. Push out 3.5" metal plate & drive cover from inside (You use a screw driver to force it out)



16. Slide in 3.5" drives and secure in place with screws.




17. Install 3.5" hidden drives such as hard drive, zip drive.



19. Screw all 3.5" hidden drives in place.



20. Find the 20-pin main power connector from power supply.




21. Plug into your motherboard. Different M/B has different Layout. Please refer to M/B user manual.




22. Find the 4-pin P4 connector from power supply. (for P4 only)




23. Plug into motherboard. (for Intel P4 motherboard only)




24. Find 2*USB cables. (USB1 & USB2)



25. Plug USB cables to your M/B. Please refer to M/B user manual.




26. Find "HDD LED" and "Reset SW" cables.




27. Plug them onto your M/B. Please refer to M/B user manual.




28. Find "Power SW" and "+P LED" "-P LED" cables and plug onto M/B. Please refer to M/B user manual.




29. Find "Case Speaker" from screw box.



30. Install Case Speaker to M/B following M/B user manual.



31. Connect case fans by linking together all 4pin female and male connectors of all fans. There will be 1*Female & 1*Male left out at each end. Connect the 4-pin Male to a 4-pin Female from power supply.



32. Find "Case Feet" in screw box. Lay case down and snap "Case Feet" on